



MRR 3 SPA – Wireless Remote

- For use with poly-planar marine systems
- Floating, waterproof design – do not remove remote from rubber housing
- Usage range 15' (5m)

CONTROL & FUNCTIONS KEYS

Power button - to turn the unit on or off.

MUTE button - to mute audio level. Press the button again to release mute function.

TUNE ▲/▼ buttons - In radio mode, to select a station In CD mode, to move to the next/previous track.

Source button - to cycle through all available sources connected to the system (e.g. RADIO mode to CD mode to AUX IN).

Auto button - In radio mode, seeks through the current 6 presets. Press and hold to automatically program the presets with the next detected stations.

Audio button - to select the audio adjustment functions on the stereo



Band button - In radio mode, to select between 3FM banks and 2AM banks.

VOL ▲/▼ buttons - Zone1, to increase/decrease volume level. Zone1, reserve for future use

Amp Source button – for MRD70 and STI120 only (see applicable user manual for details).

Preset 1 button - In radio mode, Press and hold to assign the

current station to this preset. In CD mode, enables INTRO scan function.

Preset 2 button - In radio mode, Press and hold to assign the current station to this preset. In CD mode, enables RANDOM scan function.

Preset 3 button - In radio mode, Press and hold to assign the current station to this preset. In CD mode, enables REPEAT track function.

Preset 4 button - In radio mode, Press and hold to assign the current station to this preset.

Preset 5 button - In radio mode, Press and hold to assign the current station to this preset. In CD changer mode, load and play the previous Disc .

Preset 6 button - In radio mode, Press and hold to assign the current station to this preset. In CD changer mode, load and play the next Disc.

SNC button – reserve for future use

Light button – controls the spa lighting system

Air button – controls the air blower pump

Jet 1 button – controls the main spa jet pump

Jet 2 button – controls the second spa jet pump

Jet 3 button – controls the third spa jet pump

Note: For these Spa Control buttons to work the spa must be equipped with the SPA CONTROLLER INTERFACE (available exclusively from Poly-planar).

Battery Installation

- Use battery type CR2025
- Remove remote from rubber housing
- Put a coin in the battery door slot and turn counter-clockwise
- Hook with thumbnail and pull out battery door
- Replace with fresh battery, be sure to note polarity
- Replace door. Use a coin in the slot and turn clockwise
- Replace remote firmly in rubber housing

poly-planar, inc.

Maryland USA

(410) 761-4000

www.polyplanar.com