


MRR5 Wired Remote Installation Guide

Installation: Find a suitable location making sure there is clearance for the installed depth. Use a hole saw or other suitable device to make a cutout. Please use the supplied mounting bracket.



Mounting Depth
0.67" (17mm)

